

Trouble Shooting Operating Symptoms

INSUFFICIENT PRESSURE

- 1. Speed too slow (check voltage).
- 2. Impeller trimmed incorrectly.
- 3. Impeller loose.
- 4. Impeller plugged.
- 5. Wear rings worn.
- 6. Entrained air in pump.
- 7. Leaking joints or bowl casing.
- 8. Wrong rotation.
- 9. Incorrect impeller adjustment.

NO LIQUID DELIVERED

- 1. Pump section broken (water level below inlet).
- 2. Suction valve closed.
- 3. Impeller plugged.
- 4. Strainer clogged.
- 5. Wrong rotation.
- 6. Shaft broken or unscrewed.
- 7. Impeller loose.
- 8. Barrel or discharge not vented.
- 9. Driver inoperative.

VIBRATION

- 1. Motor imbalance-electrical.
- 2. Motor bearing not properly seated or worn.
- 3. Motor drive coupling out of balance or alignment.
- Misalignment of pump, casings, discharge head column or bowls.
- Discharge head misaligned by improper mounting or pipe strain.
- 6. Bent shafting.
- 7. Worn pump bearings.
- 8. Clogged impeller or foreign material in pump.
- 9. Improper impeller adjustment.
- 10. Vortex problems in sump.
- 11. Resonance-system frequency at or near pump speed.
- 12. Cavitation.
- 13. Impeller out of balance.

INSUFFICIENT CAPACITY

- Speed too slow.
- 2. Impeller trimmed incorrectly.
- 3. Impeller loose.
- 4. Impeller or bowl partially plugged.
- 5. Leaking joints.
- 6. Strainer or suction pipe clogged.
- 7. Suction valve throttled.
- 8. Low water level.
- 9. Reverse rotation.
- 10. Insufficient submergence.
- 11. Insufficient N.P.S.H.A.
- 12. Incorrect impeller adjustment.
- 13. Worn pump.
- 14. System pressure higher than design.

USING TOO MUCH POWER

- 1. Speed too high.
- 2. Improper impeller adjustment.
- 3. Improper impeller trim.
- 4. Pump out of alignment.
- 5. Coupling out of alignment.
- 6. Pumping sand, silt or other foreign material
- 7. Lubricating oil too heavy.
- 8. Bent shaft.
- 9. Tight bearing or packing.
- 10. Specific gravity or viscosity of fluid higher than design.
- 11. Worn pump.
- 12. Damaged pump.
- 13. Partial freezing of pump liquid.

ABNORMAL NOISE

- 1. Motor noise.
- 2. Dry pump bearing.
- 3. Broken column bearing retainers.
- 4. Broken shaft or shaft enclosing tube.
- 5. Impellers dragging on bowl case.
- Cavitation due to insufficient N.P.S.H.A. and/or submergence.
- 7. Foreign material in pump.
- 8. Excessive fluid velocity in pipe system.